



1. Typical kit contents



artimex sport

2. Fit the rungs in a side rail; align the flat side of the rung with the long dimensions.



3. Use a wood block and rubber mallet if necessary to fully seat rungs.



4. Screw the rungs into a place with the short screws.



5. Fix the metal spacer in or out and then fix it in the wall.

For more information please contact us.