



1. Typical kit contents



2. Fit the rungs in a side rail; align the flat side of the rung with the long dimension. Use a rubber mallet to tap the rungs in place if necessary



3. Fit the second rail. Start at one end, and progressively engage rungs until all are seated



4. Use a wood block and rubber mallet if necessary to fully seat rungs.



5. Screw the rungs into a place with the short screws.



6. Fix the metall spacer. In or out.