

Stall Bar Assembly Instructions



1. Typical Kit Contents




2. Fit the rungs in a side rail; align the flat side of the rung with the long dimension. Use a rubber mallet to tap the rungs in place if necessary.



3. Fit the second rail. Start at one end, and progressively engage rungs until all are seated.



4. Use a wood block and rubber mallet if necessary to fully seat rungs.



5. Screw the rungs into place with the short screws. The offset rungs will require the longer 3" screws.



6. Use the 3" screws to attach the wall bars into the predrilled holes. Secure the unit to the wall with the lag bolts provided. Test the unit for stability before use.